


## Info about the additional speakers

Even if you don't use additional speakers, it's good to know:

**This button must not be pressed without additional speakers - otherwise the speaker will not work.**

This button must be pressed when using additional speakers.



To connect the cable: plug it in and turn it clockwise until it clicks into place:



To release the cable again, you have to pull the lock backwards and turn the plug to the left:

